


KNOB SERIES


HOW TO ORDER




塑膠顏色編碼 (CAP COLOR)		
中文	ENGLISH	CODE
灰色	GRAY	G
綠色	GREEN	N
黑色	BLACK	K
紅色	RED	R
白色	WHITE	W
黃色	YELLOW	Y
透明	TRANSPARENT	T




PART NUMBER	KB-R01AC-PA-□
COLOR OF KNOB	G, K, N, R, T
SERIES	A.M.ML.PT.T




PART NUMBER	KB-R02AD-PA-□
COLOR OF KNOB	K
SERIES	A.M.ML.PT.T.




PART NUMBER	KB-R02BD-PA-□
COLOR OF KNOB	K
SERIES	MS.PD




PART NUMBER	KB-R03BA-PA-□
COLOR OF KNOB	G, K, R
SERIES	MS.PD




PART NUMBER	KB-R03DA-PA-□
COLOR OF KNOB	G, K, R
SERIES	ACTUATOR (2 x 3 mm)



PART NUMBER	KB-R05AC-PC-□
COLOR OF KNOB	K, T
SERIES	A.M.ML.PT.T



HOW TO ORDER




塑膠顏色編碼 (CAP COLOR)		
中文	ENGLISH	CODE
藍色	BLUE	B
灰色	GRAY	G
綠色	GREEN	N
黑色	BLACK	K
紅色	RED	R
白色	WHITE	W
黃色	YELLOW	Y
透明	TRANSPARENT	T

	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-R06AD-PA-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>G, K, W</td> </tr> <tr> <td>SERIES</td> <td>A.M.PT.T</td> </tr> </table>	PART NUMBER	KB-R06AD-PA-□	COLOR OF KNOB	G, K, W	SERIES	A.M.PT.T	
PART NUMBER	KB-R06AD-PA-□							
COLOR OF KNOB	G, K, W							
SERIES	A.M.PT.T							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-R08AC-K-PC-Y</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>B.G.N.O.R.W.Y</td> </tr> <tr> <td>SERIES</td> <td>A.T.PT</td> </tr> </table>	PART NUMBER	KB-R08AC-K-PC-Y	COLOR OF KNOB	B.G.N.O.R.W.Y	SERIES	A.T.PT	
PART NUMBER	KB-R08AC-K-PC-Y							
COLOR OF KNOB	B.G.N.O.R.W.Y							
SERIES	A.T.PT							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-R09FF-K-PA-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>G, K, W</td> </tr> <tr> <td>SERIES</td> <td>RS003</td> </tr> </table>	PART NUMBER	KB-R09FF-K-PA-□	COLOR OF KNOB	G, K, W	SERIES	RS003	
PART NUMBER	KB-R09FF-K-PA-□							
COLOR OF KNOB	G, K, W							
SERIES	RS003							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-R10CA-PA-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>B, G, W, K, R</td> </tr> <tr> <td>SERIES</td> <td>KT</td> </tr> </table>	PART NUMBER	KB-R10CA-PA-□	COLOR OF KNOB	B, G, W, K, R	SERIES	KT	
PART NUMBER	KB-R10CA-PA-□							
COLOR OF KNOB	B, G, W, K, R							
SERIES	KT							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-R11AC-PA-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>K, T</td> </tr> <tr> <td>SERIES</td> <td>A.M.PT.T.ML</td> </tr> </table>	PART NUMBER	KB-R11AC-PA-□	COLOR OF KNOB	K, T	SERIES	A.M.PT.T.ML	
PART NUMBER	KB-R11AC-PA-□							
COLOR OF KNOB	K, T							
SERIES	A.M.PT.T.ML							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-R12BD-PA-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>K, T</td> </tr> <tr> <td>SERIES</td> <td>PD.MS</td> </tr> </table>	PART NUMBER	KB-R12BD-PA-□	COLOR OF KNOB	K, T	SERIES	PD.MS	
PART NUMBER	KB-R12BD-PA-□							
COLOR OF KNOB	K, T							
SERIES	PD.MS							

KNOB SERIES


HOW TO ORDER




塑膠顏色編碼 (CAP COLOR)		
中文	ENGLISH	CODE
暗灰	DARK GRAY	DG
亮灰	LIGHT GRAY	LG
藍色	BLUE	B
灰色	GRAY	G
綠色	GREEN	N
黑色	BLACK	K
紅色	RED	R
白色	WHITE	W
黃色	YELLOW	Y
透明	TRANSPARENT	T




PART NUMBER	KB-R13AC-PA-□
COLOR OF KNOB	K, T
SERIES	ML




PART NUMBER	KB-R15AA-PA-□
COLOR OF KNOB	K, T, W
SERIES	A.M.PT.T.ML




PART NUMBER	KB-R16AH-W-PA-□-2P
COLOR OF KNOB	K, G
SERIES	RS003




PART NUMBER	KB-R17FF-K-PA-□
COLOR OF KNOB	R, Y, N, B, W
SERIES	RS003




PART NUMBER	KB-R18DA-PA-□
COLOR OF KNOB	R, Y, N, B, W
SERIES	ACTUATOR (2 x 3 mm)



PART NUMBER	KB-R18A1A-PA-□
COLOR OF KNOB	R, Y, N, B, W
SERIES	A.M.PT.T.ML



HOW TO ORDER




塑膠顏色編碼 (CAP COLOR)		
中文	ENGLISH	CODE
暗灰	DARK GRAY	DG
亮灰	LIGHT GRAY	LG
藍色	BLUE	B
灰色	GRAY	G
綠色	GREEN	N
黑色	BLACK	K
紅色	RED	R
白色	WHITE	W
黃色	YELLOW	Y
透明	TRANSPARENT	T

	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-S04BA-PA-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>K, W</td> </tr> <tr> <td>SERIES</td> <td>MS, PD</td> </tr> </table>	PART NUMBER	KB-S04BA-PA-□	COLOR OF KNOB	K, W	SERIES	MS, PD	
PART NUMBER	KB-S04BA-PA-□							
COLOR OF KNOB	K, W							
SERIES	MS, PD							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-S07AC-PA-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>G, K, W</td> </tr> <tr> <td>SERIES</td> <td>A.M, PT, T</td> </tr> </table>	PART NUMBER	KB-S07AC-PA-□	COLOR OF KNOB	G, K, W	SERIES	A.M, PT, T	
PART NUMBER	KB-S07AC-PA-□							
COLOR OF KNOB	G, K, W							
SERIES	A.M, PT, T							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-S07BC-PA-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>G, K, W</td> </tr> <tr> <td>SERIES</td> <td>PD, MS</td> </tr> </table>	PART NUMBER	KB-S07BC-PA-□	COLOR OF KNOB	G, K, W	SERIES	PD, MS	
PART NUMBER	KB-S07BC-PA-□							
COLOR OF KNOB	G, K, W							
SERIES	PD, MS							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-S14AC-PA-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>G, K</td> </tr> <tr> <td>SERIES</td> <td>A.M, PT, T</td> </tr> </table>	PART NUMBER	KB-S14AC-PA-□	COLOR OF KNOB	G, K	SERIES	A.M, PT, T	
PART NUMBER	KB-S14AC-PA-□							
COLOR OF KNOB	G, K							
SERIES	A.M, PT, T							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-S19AC-PC-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>G, K, W</td> </tr> <tr> <td>SERIES</td> <td>A.M, PT, T</td> </tr> </table>	PART NUMBER	KB-S19AC-PC-□	COLOR OF KNOB	G, K, W	SERIES	A.M, PT, T	
PART NUMBER	KB-S19AC-PC-□							
COLOR OF KNOB	G, K, W							
SERIES	A.M, PT, T							
	<table border="1"> <tr> <td>PART NUMBER</td> <td>KB-S20CD-PC-□</td> </tr> <tr> <td>COLOR OF KNOB</td> <td>G, K</td> </tr> <tr> <td>SERIES</td> <td>ACTUATOR (2.45 x 2.45mm)</td> </tr> </table>	PART NUMBER	KB-S20CD-PC-□	COLOR OF KNOB	G, K	SERIES	ACTUATOR (2.45 x 2.45mm)	
PART NUMBER	KB-S20CD-PC-□							
COLOR OF KNOB	G, K							
SERIES	ACTUATOR (2.45 x 2.45mm)							

KNOB SERIES


HOW TO ORDER



塑膠顏色編碼 (CAP COLOR)		
中文	ENGLISH	CODE
暗灰	DARK GRAY	DG
亮灰	LIGHT GRAY	LG
藍色	BLUE	B
灰色	GRAY	G
綠色	GREEN	N
黑色	BLACK	K
紅色	RED	R
白色	WHITE	W
黃色	YELLOW	Y
透明	TRANSPARENT	T



PART NUMBER	KB-R21BC-PA-□
COLOR OF KNOB	K, W
SERIES	MS.PD



PART NUMBER	KB-R22AC-PC-□
COLOR OF KNOB	G, K, W
SERIES	A.M.PT.T

